


Folding the box

The box consists of a upper and a lower part. In the delivery condition all the buckling edges are stamped and the short sides are already folded. First of all you should fold all sides once by 90 degrees to simplify the assembly. On the short sides there are two tabs and a standing edge. You should fold them by 45 degrees. The photos are showing the buckling direction. Now you can fold the short and the long sides. Please note that the corners have to be folded towards the short sides (see photo). Finished - now you can put the discs and the manual into the box.

1.



2.



3.



4.

